

# TWS-40

## True Wireless Earbud



### Manual

## How to Use

With Bluetooth wireless technology, you cannot your headset to a compatible device. The maximum distance the phone and device should not exceed 10 meters, otherwise the Bluetooth wireless connection may be disturbed by obstacles such as wall or other electronic devices.

1. Take the headset out of the charging case. The LED lights will flash red and blue alternately. They will automatically connect within 1 to 5 minutes. If one of the earbuds turns blue and the other earbud is still flashing red and blue, then both earbuds have been paired with eachother.

**Note:** If they are both flashing red and Blue lights alternatively, place the earbuds back in the charging case and shut down. Wait a few seconds before taking them out again and pairing again.

## How to Use

2. When the earbuds are successfully paired with eachother, open the Bluetooth settings on your device and search for "TWS". Click to connect.

3. When the headsets have been connected during the first use, they will automatically connect after every use there after. If the connection is not available, repeat step 2.

**Note:** To pair another mobile device, please follow Step 1.

## Charging

A. To charge the headset, place both earbuds into the charging case until the red light turns off, which indicates the battery is fully charged.

B. If the headsets are not used for a long time, in order to extend the battery life, it is recommended to fully charge the headsets and the battery charging case every month. In addition, if they are not used for a long time, the charging indicator will be delayed for a few seconds.

## Warnings

1. Since the earbuds are in the charging case for a long time, the charging case will always charge the earbuds until the battery is exhausted. When the charging case has no power, the earbuds will not automatically turn on when they are taken out.

2. At this time, you can press and hold the earbuds' switch button to turn on for automatic pairing. For the battery life of earbuds and charging case, please charge the charging case at least once a month if it is not used in a long time.

**Tips:** Due to its own characteristics, true wireless earphone products may experience intermittent playback in an environment with a very high degree of wireless interference.

## Specifications

Wireless Version: V5.0
Working Distance: 10m
Impedance: 32Ω
Driver: φ 10mm
Frequency Response: 20Hz-20kHz
Speaker Sensativity: 95 ± 3dB
Music Time: 2 Hrs
Talk Time: 2 Hrs
Standby Time: 100 Hrs
Charging Time: 2 Hrs
Battery: 40 mAh-single headset
Charging Case Battery: 300mAh